STIL - USB interface module

The STIL-USB interface is required for hardware specific parameter setup of the STDL drive.
It is used together with the setup software “STDL Workspace” installed on any Windows PC.
The STIL-USB interface itself is ready to use.
The STIL-USB interface works as a safe and galvanic separating bridge between your PC and the STDL hardware.



Every care has been taken to ensure the accuracy of the information in this document, but we take no liability for any errors or omissions. We reserve the right to make changes without prior notice.

Every care has been taken to ensure the accuracy of the information in this document, but we take no liability for any errors or omissions. We reserve the right to make changes without prior notice.