Bellow

Bellow for QME Linear Unit.
Note that “stroke” for a L+R unit refers to the stroke of each individual slider.
Bellows are recommended for all applications where the unit isn’t protected against dust and dirt. The bellow may also work as a squeeze protection.



Dimensions in mm.

Every care has been taken to ensure the accuracy of the information in this document, but we take no liability for any errors or omissions. We reserve the right to make changes without prior notice.

General Data

Designation	Bellow Ltot	Bellow R+L Ltot
QME12-B	stroke * 1.286 + 110	stroke * 2.572 + 195
QME20-B	stroke * 1.200 + 162	stroke * 2.4 + 292
QME30-B	stroke * 1.146 + 234	stroke * 2.292 + 434

Every care has been taken to ensure the accuracy of the information in this document, but we take no liability for any errors or omissions. We reserve the right to make changes without prior notice.