





## Automatic Butt Connector

Use the automatic butt connector to quickly and easily link the face ends of two profiles from the same series without having to machine the profiles beforehand. Best practice is to use the automatic butt connectors in pairs. You may need several pairs, depending on the size and load on the profiles. Package includes the screw and cutting bush.


Note: The load values refer to connectors installed in pairs

**System:** 30 - Slot 6; 20 - Slot 5; 40 - Slot 8

**Type:** Fasteners



## General Data



Designation	Description	System	M (Nm)	F (N)
<b>PV4040</b>	Set of automatic butt connectors	20 - Slot 5	22	1500
<b>PV1209</b>	Set of automatic butt connectors	20 - Slot 5	22	1500
<b>PV3050</b>	Set of automatic butt connectors	30 - Slot 6	45	1800
<b>PV1210</b>	Set of automatic butt connectors	30 - Slot 6	45	1800
<b>PV1105</b>	Set of automatic butt connectors	40 - Slot 8	140 (40x40L) / 170 (40x40)	4500